





Macintosh Setup Poster 安装海报


HP Deskjet 6600 series



1




2




3

Verify printer is on.
确认打印机电源已打开。




4

Load white paper. Lower tray.
装入白纸。放下纸盘。



5

Open cover.
打开机盖。



6


Pull pink tab to remove clear tape.
拉下粉红色标签以移除透明胶带。




7

Wait until cradle is idle. Raise latches, insert print cartridges, then close latches.
等待直到底座闲置。提起门锁，插入打印墨盒，然后关上门锁。


1



2




3



8

Close cover.
关上机盖。




9

Choose one option for connecting to the printer: Ethernet or USB.

选择连接到计算机的其中一个选项：以太网或 USB。

Ethernet



Verify that the network is set up, powered on, and functioning properly.
确认网络经已设置、打开电源，并正常操作。

1



Use the included Ethernet cable to connect the printer to the network hub, switch, or router.
使用随附的以太网电缆将打印机连接到网络集线器、交换机，或路由器。

2

Verify that the Network icon is on. If not, check the cable connections.
确认“网络”图象亮起。若未亮起，请检查电缆连接。


3

Insert CD, double-click the CD icon in the Finder window, and then double-click the Installer icon.
放入 CD，在 Finder 窗口中连接 CD 图象，然后连接“安装器”图象。





- Or - -或-

USB



Connect printer to computer. Insert CD, double-click the CD icon in the Finder window, and then double-click the Installer icon.
将打印机连接到计算机。放入 CD，在 Finder 窗口中连接 CD 图象，然后连接“安装器”图象。



See the reference guide for more installation information.
请参阅参考指南以获取更多安装信息。

Need help? www.hp.com/support

需要帮助? www.hp.com/support